


STM POWERSPORTS RAGE 8 30MM STD

STM Powersports Pneumatic Primary Clutch Part Number 1001454 US PAT. 10,744,944 B2 & US 2009/0227404A1



www.stmpowersports.com

STM POWERSPORTS RAGE 8 30MM STD



n.		
M Powersports Pneuma	atic	Prima


US PAT. 10.744.944 B2 & US 2009/0227404A1

Item No.Part NumberDescription1VH131Bushing Retaining Clip21816Bushing for Cover Stop31001564Pneumatic Primary Cover Stop-SHCS Style41001095Snowmobile Primary 4 & 8 Arm Cover Screw Set (reque to 125 in/1592196A534½"-20 x 5/16" SCHS SHCS Screw for Pneumatic61001581Pneumatic Rage 4 & 8 STD Lock Up Primary Cover73001005Spider Nut Rage Primary (Torque to 550 ft/lbs. use green 638 Locttle81001264Rage 8 Screw-on Spider (Torque to 500 ft/lbs. use green 638 Locttle91001439Pneumatic Primary Rage 8 Movable Sheave109670K23Pneumatic Primary Steel Lock Up Ball111001335 -sold only with line 13Pneumatic Primary Steel Lock Up Ball1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Clutch Plunger Bearing161001312Pneumatic Clutch Plunger Bearing171001280Pneumatic Primary Plunger181001293Pneumatic Primary Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Basering Block21R18>2RSPneumatic Primary Basering Block Baring231001292Pneumatic Clutch #10-32 x 1.5 SHCS Batring Snap Ring2491306A345Pneumatic Clutch #10-32 x 1.5 SHCS Button Head Screw2591251A351Pneumatic Clutch #10-32 x 1.5 SHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449 <th></th>	
21816Bushing for Cover Stop31001564Pneumatic Primary Cover Stop-SHCS Style41001095Snowmobile Primary 4 & 8 Arm Cover Screw Set (Torque to 125 In/1592196A534¼"-20 x 5/16" SCHS SHCS Screw for Pneumatic61001581Pneumatic Rage 4 & 8 STD Lock Up Primary Cover73001005Spider Nut Rage Primary (Torque to 550 ft/lbs. use red Loctite81001264Rage 8 Screw-on Spider (Torque to 500 ft/lbs. use red Loctite91001439Pneumatic Primary Rage 8 Movable Sheave109670K23Pneumatic Primary Steel Lock Up Ball111001335 -sold only with line 13Pneumatic Primary Fixed Sheave Blank1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Clutch Plunger Bearing161001312Pneumatic Clutch Plunger Bearing171001280Pneumatic Primary Plunger Shaft191001293Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Primary Clutch Head Screw2491306A345Pneumatic Clutch #10-32 x 1.5 BHCS BUTOn Head Screw2591251A351Pneumatic Primary Bearing Block Bearing Snap Ring231001292Pneumatic Primary Clutch Bolt (Torque to 80 tt/lb2491306A345Pneumatic Primary Bearing Block Head Screw2591251A351Pneumatic Primary Bearing Bolt (Torque to 80 tt/lb	Qty.
31001564Pneumatic Primary Cover Stop-SHCS Style41001095Snowmobile Primary 4 & 8 Arm Cover Screw Set (torque to 126 in/1592196A534¼4"-20 x 5/16" SCHS SHCS Screw for Pneumatic61001581Pneumatic Rage 4 & 8 STD Lock Up Primary Cover73001005Spider Nut Rage Primary (Torque to 550 ft/lbs. use red Locttler81001264Rage 8 Screw-on Spider (torque to 500 ft/lbs. use green 638 Locttle91001439Pneumatic Primary Steel Lock Up Ball111001335 -sold only with line 13Pneumatic Primary Steel Lock Up Ball111001527Belt Shim for Primary's with 1.875" Dia. Post131001527Belt Shim for Primary's with 1.875" Dia. Post1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Lock Up Plunger Bearing161001312Pneumatic Primary Plunger Shaft191001280Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing231001292Pneumatic Primary Gluck Bearing Snap Ring2491306A345Pneumatic Clutch #10-24 x 5/8 BHCS Sutton Head Screw2591251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.95" Pneumatic Primary Bearing Bot (Torque to 80 ft/lb.)291001173Rage Primary Quick Adjust Shim .030303012	1
41001095Snowmobile Primary 4 & 8 Arm Cover Screw Set (Torque to 125 In/1)592196A534'4''-20 x 5'/16" SCHS SHCS Screw for Pneumatic61001581Pneumatic Rage 4 & 8 STD Lock Up Primary Cover73001005Spider Nut Rage Primary (Torque to 550 ft/lbs. use red Locttled81001264Rage 8 Screw-on Spider (Torque to 550 ft/lbs. use green 638 Locttlee91001439Pneumatic Primary Rage 8 Movable Sheave109670K23Pneumatic Primary Steel Lock Up Ball111001335 -sold only with line 13Pneumatic Primary Steel Lock Up Ball111001527Belt Shim for Primary's with 1.875" Dia. Post131001336 -sold only with line 11Pneumatic Primary Fixed Sheave Blank1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Lock Up Plunger Bearing161001312Pneumatic Clutch Plunger Bearing171001280Pneumatic Primary Bearing Black201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block2291985A261Pneu. Primary Bearing Block Bearing231001292Pneumatic Primary Gaung Shart2491306A345Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.95" Pneumatic Primary Bearing Bol (Torque to 80 ft/lb.)281001291Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.95" Pneumatic Primary Bearing Bolt (Torque to 80 ft/lb.)2810	1
41001095Snowmobile Primary 4 & 8 Arm Cover Screw Set (Torque to 125 m/1)592196A534'4''-20 x 5'/16" SCHS SHCS Screw for Pneumatic61001581Pneumatic Rage 4 & 8 STD Lock Up Primary Cover73001005Spider Nut Rage Primary (Torque to 550 ft/lbs. use red Locttled81001264Rage 8 Screw-on Spider (Torque to 550 ft/lbs. use green 638 Locttlee91001439Pneumatic Primary Rage 8 Movable Sheave109670K23Pneumatic Primary Stel Lock Up Ball111001325 -sold only with line 13Pneumatic Primary Stel Lock Up Ball111001527Belt Shim for Primary's with 1.875" Dia. Post131001336 -sold only with line 11Pneumatic Primary Fixed Sheave Blank1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Lock Up Plunger Bearing161001312Pneumatic Clutch Plunger Bearing171001280Pneumatic Primary Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing231001290Pneumatic Primary Bearing Block Bearing2491306A345Pneumatic Clutch #10-24 x 5'/s BHCS Socket Head Screw2710014493/2-20 x 3.955" Pneumatic Primary Bearing Bolt (Torque to 80 ft/lib.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool <td>1</td>	1
61001581Pneumatic Rage 4 & 8 STD Lock Up Primary Cover73001005Spider Nut Rage Primary (Torque to 550 ft/lbs. use red Loctited81001264Rage 8 Screw-on Spider (Torque to 500 ft/lbs. use green 638 Loctite91001439Pneumatic Primary Rage 8 Movable Sheave109670K23Pneumatic Primary Steel Lock Up Ball111001335 - sold only with line 13Pneumatic Primary Steel Lock Up Ball121001527Belt Shim for Primary's with 1.875" Dia. Post131001336 - sold only with line 11Pneumatic Primary Fixed Sheave Blank1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Clutch Plunger Bearing161001312Pneumatic Cock Up Plunger Bearing171001280Pneumatic Primary Plunger Shaft191001293Pneumatic Primary Bearing Back (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing231001292Pneumatic Primary Clutch Bolt (Torque to 80 ft/lbs.)2491306A345Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw2591251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.955" Pneumatic Primary Clutch Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .03030 <td< td=""><td>1</td></td<>	1
61001581Pneumatic Rage 4 & 8 STD Lock Up Primary Cover73001005Spider Nut Rage Primary (Torque to 550 ft/lbs. use red Loctited81001264Rage 8 Screw-on Spider (Torque to 500 ft/lbs. use green 638 Loctite91001439Pneumatic Primary Rage 8 Movable Sheave109670K23Pneumatic Primary Steel Lock Up Ball111001335 - sold only with line 13Pneumatic Primary Steel Lock Up Ball121001527Belt Shim for Primary's with 1.875" Dia. Post131001336 - sold only with line 11Pneumatic Primary Fixed Sheave Blank1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Clutch Plunger Bearing161001312Pneumatic Lock Up Plunger Bearing171001280Pneumatic Primary Plunger Shaft191001293Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block2291985A261Pneu. Primary Bearing Block Bearing231001292Pneumatic Primary Cylinder Mount2491306A345Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.955" Pneumatic Primary Clutch Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	3
73001005Spider Nut Rage Primary (Torque to 550 ft/lbs. use red Locttled81001264Rage 8 Screw-on Spider (Torque to 500 ft/lbs. use green 638 Locttled91001439Pneumatic Primary Rage 8 Movable Sheave109670K23Pneumatic Primary Rage 8 Movable Sheave111001335 -sold only with line 13Pneumatic Primary Steel Lock Up Ball111001336 -sold only with line 11Pneumatic Primary is with 1.875" Dia. Post131001336 -sold only with line 11Pneumatic Primary Fixed Sheave Blank1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Clutch Plunger Bearing161001312Pneumatic Primary Plunger Bearing Spacer171001280Pneumatic Primary Blase (Torque to 75 ft/lbs.)201001293Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing231001292Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Bearing Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	1
81001264Rage 8 Screw-on Spider (Torque to 500 ft/lbs. use green 638 Loctite91001439Pneumatic Primary Rage 8 Movable Sheave109670K23Pneumatic Primary Steel Lock Up Ball111001335 -sold only with line 13Pneumatic Primary Steel Lock Up Ball121001527Belt Shim for Primary's with 1.875" Dia. Post131001336 -sold only with line 11Pneumatic Primary Fixed Sheave Blank1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Lock Up Plunger Bearing161001312Pneumatic Lock Up Plunger Bearing Spacer171001280Pneumatic Primary Plunger181001293Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing231001292Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Bearing Blot (Torque to 60 ft/lbs.)291001173Rage Primary Bearing Blot (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	1
91001439Pneumatic Primary Rage 8 Movable Sheave109670K23Pneumatic Primary Steel Lock Up Ball111001335 -sold only with line 13Pneumatic Primary Post121001527Belt Shim for Primary's with 1.875" Dia. Post131001336 -sold only with line 11Pneumatic Primary Fixed Sheave Blank1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Clutch Plunger Bearing161001312Pneumatic Clutch Plunger Bearing Spacer171001280Pneumatic Primary Plunger181001293Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Clutch #10-24 x 5/s BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Clutch Bolt (Torque to 80 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	
109670K23Pneumatic Primary Steel Lock Up Ball111001335 -sold only with line 13Pneumatic Primary Post121001527Belt Shim for Primary's with 1.875" Dia. Post131001336 -sold only with line 11Pneumatic Primary Fixed Sheave Blank1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Clutch Plunger Bearing161001312Pneumatic Lock Up Plunger Bearing Spacer171001280Pneumatic Primary Plunger181001293Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing231001292Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Clutch Bolt (Torque to 80 ft/lbs.)291001173Rage Primary Bearing Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	
111001335 - sold only with line 13Pneumatic Primary Post121001527Belt Shim for Primary's with 1.875" Dia. Post131001336 - sold only with line 11Pneumatic Primary Fixed Sheave Blank1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Clutch Plunger Bearing161001312Pneumatic Lock Up Plunger Bearing Spacer171001280Pneumatic Primary Plunger181001293Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Clutch Bolt (Torque to 80 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	_
121001527Belt Shim for Primary's with 1.875" Dia. Post131001336 - sold only with line 11Pneumatic Primary Fixed Sheave Blank1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Clutch Plunger Bearing161001312Pneumatic Lock Up Plunger Bearing Spacer171001280Pneumatic Primary Plunger181001293Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Clutch #10-24 x 5/8 BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Bearing Bolt (Torque to 80 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	6
131001336 - sold only with line 11Pneumatic Primary Fixed Sheave Blank1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Clutch Plunger Bearing161001312Pneumatic Lock Up Plunger Bearing Spacer171001280Pneumatic Primary Plunger181001293Pneumatic Primary Plunger Shaft191001290Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block Bearing21R18-2RSPneumatic Primary Bearing Block Bearing231001292Pneumatic Primary Bearing Block Bearing231001292Pneumatic Clutch #10-24 x 5/8 BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449¼-20 x 3.965" Pneumatic Primary Bearing Bolt (Torque to 80 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	1
1491255A275Plunger Retaining Screw 10-32 x 1.5 BHCS15R32RSPneumatic Clutch Plunger Bearing161001312Pneumatic Lock Up Plunger Bearing Spacer171001280Pneumatic Primary Plunger181001293Pneumatic Primary Plunger Shaft191001290Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Clutch #10-24 x ⁵ / ₈ BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Clutch Bolt (Torque to 80 ft/lb.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	1
15R32RSPneumatic Clutch Plunger Bearing161001312Pneumatic Lock Up Plunger Bearing Spacer171001280Pneumatic Primary Plunger181001293Pneumatic Primary Plunger Shaft191001290Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block Bearing21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Clutch #10-32 x 1.5 SHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Bearing Blot (Torque to 80 ft/lb.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	1
161001312Pneumatic Lock Up Plunger Bearing Spacer171001280Pneumatic Primary Plunger181001293Pneumatic Primary Plunger Shaft191001290Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block Bearing21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Clutch #10-24 x 5/8 BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Bearing Bolt (Torque to 80 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	1
171001280Pneumatic Primary Plunger181001293Pneumatic Primary Plunger Shaft191001290Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Clutch #10-24 x 5/8 BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Clutch Bolt (Torque to 80 ft/lb.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	2
181001293Pneumatic Primary Plunger Shaft191001290Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Primary Cylinder Mount2491306A345Pneumatic Clutch #10-24 x 5/8 BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Bearing Bolt (Torque to 80 ft/lb281001291Pneumatic Primary Bearing Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	1
191001290Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Primary Cylinder Mount2491306A345Pneumatic Clutch #10-24 x 5/8 BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Bearing Bolt (Torque to 80 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	1
191001290Pneumatic Primary Bearing Base (Torque to 75 ft/lbs.)201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Primary Cylinder Mount2491306A345Pneumatic Clutch #10-24 x 5/8 BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Bearing Bolt (Torque to 80 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	1
201001286Pneumatic Primary Bearing Block21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Primary Cylinder Mount2491306A345Pneumatic Clutch #10-24 x 5/8 BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Clutch Bolt (Torque to 80 ft/ll281001291Pneumatic Primary Bearing Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	1
21R18-2RSPneumatic Primary Bearing Block Bearing2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Primary Cylinder Mount2491306A345Pneumatic Clutch #10-24 x 5/8 BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Clutch Bolt (Torque to 80 ft/ll281001291Pneumatic Primary Bearing Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	
2291985A261Pneu. Primary Bearing Block Bearing Snap Ring231001292Pneumatic Primary Cylinder Mount2491306A345Pneumatic Clutch #10-24 x 5/8 BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Clutch Bolt (Torque to 80 ft/lb281001291Pneumatic Primary Bearing Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	1
231001292Pneumatic Primary Cylinder Mount2491306A345Pneumatic Clutch #10-24 x 5/8 BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Clutch Bolt (Torque to 80 ft/ll281001291Pneumatic Primary Bearing Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	
2491306A345Pneumatic Clutch #10-24 x 5/8 BHCS Button Head Screw2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Clutch Bolt (Torque to 80 ft/lk281001291Pneumatic Primary Bearing Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	_
2691251A351Pneumatic Clutch #10-32 x 1.5 SHCS Socket Head Screw271001449½-20 x 3.965" Pneumatic Primary Clutch Bolt (Torque to 80 ft/lk281001291Pneumatic Primary Bearing Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	
271001449½-20 x 3.965" Pneumatic Primary Clutch Bolt (Torque to 80 ft/lk281001291Pneumatic Primary Bearing Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	
281001291Pneumatic Primary Bearing Bolt (Torque to 60 ft/lbs.)291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	
291001173Rage Primary Quick Adjust Shim .030303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool) 1
303012.62Movable Sheave Bushing w/VH225 Retaining Clip311001501Pneumatic Primary Cover Stop Clutch Spanner Tool	1
31 1001501 Pneumatic Primary Cover Stop Clutch Spanner Tool	1
	1
The following parts are included but NOT SHOWN on the breakdown:	1
1001498 Pneu. Primary Clutch Puller 30mm 1 1001032 Rage 4 & 8 Spanner Tool	1
1001091 TRA Spring Spacer 2 1001006 1 st Stage 8 Arm M5 Fastner Kit	1
1001569 Pneu. Primary Compression Tool 1 1001580 Pneumatic Clutch Cover Holding To	I 1
LOO1023 Rage 6 & 8 1 st Stage Arm Pin Assy 4 1001040 Rage 8 Movable Roller .312 Set (
L001041 Rage 8 Movable Roller .500 Set (4) 1 1001042 Rage 8 Movable Roller .625 Set (
LOO1028 Movable Roller Pin Assy 4 1001024 1 st Stage HD M5 Arms	4
LOO1330 1 st Stage Cam Arm Bushing 4	
Local Control Local Control <thlocal contro<="" th=""> <thlocal control<="" td="" th<=""><td>1</td></thlocal></thlocal>	1
Kit for Rage 4 & 8 Spider Non-Wide Adjustment Set Screw Set	
Conversion pin options (not show-only 1 size is included & used) Qty needed: 4	
1001319 5/16" Fixed Pin for .570 Wide Weight 1001320 5/16" Non-Fixed Pin for .570 V	de Weight
1001321 5/16" Fixed Pin for .470 Wide Weight 1001322 5/16" Non-Fixed Pin for .470 V	U
1001326 8MM Pin for Yamaha Weight	morgin





mary Clutch Part Number 1001454



ITEM #	PART NUMBER	DESCRIPTION	QTY
25	C24005D	Pneumatic Primary Cylinder	1
2	ME14-18N	Pneumatic Primary Air Tube Fitting	5
3	PT 14-316 NAT	Pneumatic Primary Air Tubing	10 FT
4	MSC-05681499	Pneumatic Primary Air Valve	1

9/13/2023

STM POWERSPORTS RAGE 8 30MM STD



STM Powersports Pneumatic Primary Clutch Part Number 1001454

US PAT. 10,744,944 B2 & US 2009/0227404A1